


Quick Configuration

1. Connect a Hub and a PC as the diagram shown below. Power on the PC, Hub and make sure the PC is running Windows.



2. Make sure the .NETpower card is powered on.
 3. Insert the .NETpower management CD-ROM into the CD-ROM drive.
 4. Start Small Configuration program (smconfig.exe) on the CD-ROM to configure the .NETpower device. It can search and display the .NETpower devices on the LAN and allow you to configure the network settings and much more settings, such as time settings, SNMP controls, UPS properties...
- (The default username is **root**, the default password is **synso**.)